

<u>Appendix G</u> <u>Event/Action Plan for Water Quality</u> <u>Exceedance</u>

The copyright of this document is owned by Acuity Sustainability Consulting Limited. It may not be reproduced except with prior written approval from the Company.



EVENT	ACTION				
	ET	IEC	ER	CONTRACTOR	
Action level being exceeded by one sampling day	 Repeat <i>in-situ</i> measurement to confirm findings; Identify reasons for non- compliance and source(s) of impact; Inform IEC and Contractor; Check monitoring data, all plants, equipment and Contractor's working methods; Discuss mitigation measures with IEC and Contractor; (The above actions should be taken within 1 working day after the exceedance is identified) Repeat measurement on next day of exceedance. 	 Discuss with ET and Contractor on the mitigation measures; Review proposals on mitigation measures submitted by Contractor and advise the ER accordingly; Assess the effectiveness of the implemented mitigation measures. (The above actions should be taken within 1 working day after the exceedance is identified) 	 Discuss with IEC on the proposed mitigation measures; Make agreement on the mitigation measures to be implemented. Assess the effectiveness of the implemented mitigation measures (The above actions should be taken within 1 working day after the exceedance is identified) 	 Inform the ER and confirm notification of the non- compliance in writing; Rectify unacceptable practice; Check all plants and equipment; Consider changes of working methods; Discuss with ET and IEC and propose mitigation measures to IEC and ER; Implement the agreed mitigation measures. (The above actions should be taken within 1 working day after the exceedance is identified) 	
Action level being exceeded by more than one consecutive sampling days	 Repeat <i>in-situ</i> measurement to confirm findings; Identify reasons for non- compliance and source(s) of impact; Inform IEC and Contractor; Check monitoring data, all plants, equipment and Contractor's working methods; Discuss mitigation measures with IEC and Contractor; Ensure mitigation measures are implemented; Prepare to increase the monitoring frequency to daily; (The above actions should be taken within 1 working day after the exceedance is identified) Repeat measurement on next working day of exceedance. 	 Discuss with ET and Contractor on the mitigation measures; Review proposals on mitigation measures submitted by Contractor and advise the ER accordingly; Assess the effectiveness of the implemented mitigation measures. (The above actions should be taken within 1 working day after the exceedance is identified) 	 Discuss with IEC on the proposed mitigation measures; Make agreement on the mitigation measures to be implemented; Assess the effectiveness of the implemented mitigation measures. (The above actions should be taken within 1 working day after the exceedance is identified) 	 Inform the ER and confirm notification of the non- compliance in writing; Rectify unacceptable practice; Check all plants and equipment; Consider changes of working methods; Discuss with ET and IEC and propose mitigation measures to IEC and ER within 3 working days; Implement the agreed mitigation measures. (The above actions should be taken within 1 working day after the exceedance is identified) 	

The copyright of this document is owned by Acuity Sustainability Consulting Limited. It may not be reproduced except with prior written approval from the Company.



EVENT	ACTION				
	ET	IEC	ER	CONTRACTOR	
Limit level being exceeded by one sampling day	 Repeat <i>in-situ</i> measurement to confirm findings; Identify reasons for non- compliance and source(s) of impact; Inform IEC, Contractor and EPD 	 Discuss with ET and Contractor on the mitigation measures; Review proposals on mitigation measures submitted by Contractor and advise the ER accordingly; 	 Discuss with IEC, ET and Contractor on the proposed mitigation measures; Request Contractor to critically review the working methods; Make agreement on the 	 Inform the ER and confirm notification of the non- compliance in writing; Rectify unacceptable practice; Check all plants and equipment; Consider changes of working 	
	 Check monitoring data, all plants, equipment and Contractor's working methods; Discuss mitigation measures with IEC, ER and Contractor; 	 Assess the effectiveness of the implemented mitigation measures. (The above actions should be taken within 1 working day after 	mitigation measures to be implemented;4. Assess the effectiveness of the implemented mitigation measures.	methods; 5. Discuss with ET, IEC and ER and Propose mitigation measures to IEC and ER within 3 working days;	
	 Ensure mitigation measures are implemented; Increase the monitoring frequency to daily until no exceedance of Limit level. 	the exceedance is identified)	 (The above actions should be taken within 1 working day after the exceedance is identified) 	 Implement the agreed mitigation measures 	
	 (The above actions should be taken within 1 working day after the exceedance is identified) 				
Limit level being	1. Repeat <i>in-situ</i> measurement to	1. Discuss with ET and Contractor	1. Discuss with IEC, ET and	1. Inform the ER and confirm	
exceeded by more than one consecutive	 confirm findings; Identify reasons for non- compliance and source(s) of impact; 	 on the mitigation measures; Review proposals on mitigation measures submitted by Contractor and advise the ER 	 Contractor on the proposed mitigation measures; Request Contractor to critically review the working methods; 	notification of the non- compliance in writing; 2. Rectify unacceptable practice; 3. Check all plants and equipment;	
sampling day	 Inform IEC, Contractor and EPD, Check monitoring data, all plants, equipment and Contractor's working methods; 	accordingly;3. Assess the effectiveness of the implemented mitigation measures.	 Make agreement on the mitigation measures to be implemented; Assess the effectiveness of the 	 Consider changes of working methods; Discuss with ET, IEC and ER and Propose mitigation measures to 	
	 Discuss mitigation measures with IEC, ER and Contractor; Ensure mitigation measures are implemented; 	 (The above actions should be taken within 1 working day after the exceedance is identified) 	implemented mitigation measures.5. Consider and instruct, if necessary, the Contractor to	IEC and ER within 3 working days; 6. Implement the agreed mitigation measures;	
	 Increase the monitoring frequency to daily until no exceedance of Limit level for 2 consecutive days. 		slow down or to stop all or part of the dredging and sand filling work until no exceedance of Limit level.	 As directed by the ER, to slow down or stop all or part of the dredging and sand filling work. 	
	 (The above actions should be taken within 1 working day after the exceedance is identified) 		6. (The above actions should be taken within 1 working day after the exceedance is identified)		

The copyright of this document is owned by Acuity Sustainability Consulting Limited. It may not be reproduced except with prior written approval from the Company.